


WHEN DISASSEMBLING TIGHTEN ALL BLACK KNOBS TO PREVENT LOSS DURING SHIPPING



## Order #xxxxx - P20 - Ben Jamin - Backwall Assembly



## WHEN DISASSEMBLING TIGHTEN ALL BLACK KNOBS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

866.652.2100




Assure that a good connection is made and tighten to secure.

Step stool may be required

© 2008

### Order #xxxxx - P20 - Ben Jamin - Backwall Assembly cont'd




WHEN DISASSEMBLING TIGHTEN ALL BLACK KNOBS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

© 2008


### Page 2 of 8

### Order #xxxxx - P20 - Ben Jamin - Backwall Assembly (Cont'd)



## Step 3

### Order #xxxxx - P20 - Ben Jamin - Backwall Assembly (Cont'd)




www.classicexhibits.com

## Step 4

© 2008


### Page 4 of 8



# WHEN DISASSEMBLING TIGHTEN ALL BLACK KNOBS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com


## Step 5



© 2008

## Page 5 of 8

### **Order #xxxxx - P20 - Ben Jamin - Header, Shelf and Cubby Assembly**



# WHEN DISASSEMBLING TIGHTEN ALL BLACK KNOBS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

866.652.2100

© 2008

### Page 6 of 8

## Order #xxxxx - P20 - Ben Jamin - Workstation Assembly - Qty. 2

Part Number	Description
А	Left Leg Assembly
В	Right Leg Assembly
С	Horizontal Extrusion

D Horiontal Extrusion w/ Door Stopper

Step 1:


A) Connect lower horizontal extrusion [C] between bottom of leg assemblies [A and B] as shown.


B) Insert Laminated infill into grooves of leg assemblies [A and B].

C) Attach extrusion door between leg assemblies [A and B] and atop laminated infill.

D) Attach upper horizontal extrusion w/ door stopper [D] between leg assemblies [A and B], and set flush with top of legs [A and B].

NOTE: Make sure the lock is flush with extrusion before tightening. If lock will not fully engage, gently rock lock and extrusion while turning knob until lock fully opens.





# WHEN DISASSEMBLING TIGHTEN ALL BLACK KNOBS TO PREVENT LOSS DURING SHIPPING

## Step 7

866.652.2100

© 2008

Page 7 of 8

Part Number	Description
Е	Horizontal Extrusion
F	Horizontal Extrusion

### Step 2:


A) Attach horizontal extrusion [E] between vertical leg assemblies [A and B] as shown below.


B) Insert Laminated infill into grooves of vertical leg assemblies [A and B].

C) Attach upper horizontal extrusion [F] between vertical leg assemblies [A and B] atop infill.

D) Place internal shelf into assembled pedestal atop pins.

E) Set Counter atop assembled pedestal and secure with Velcro straps attached to underside of top.





www.classicexhibits.com


## Step 8

### 866.652.2100

© 2008

### Page 8 of 8


Case #1 - Backwall Components



WHEN DISASSEMBLING TIGHTEN ALL BLACK KNOBS TO PREVENT LOSS DURING SHIPPING




Case # 2 - Backwall Components



WHEN DISASSEMBLING TIGHTEN ALL BLACK KNOBS TO PREVENT LOSS DURING SHIPPING


www.classicexhibits.com

### 866.652.2100



### Level 1

Case #3 - Backwall Components




WHEN DISASSEMBLING TIGHTEN ALL BLACK KNOBS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

### 866.652.2100

Case # 4 - Backwall Components



Top View of each Level


WHEN DISASSEMBLING TIGHTEN ALL BLACK KNOBS TO PREVENT LOSS DURING SHIPPING

www.classicexhibits.com

### 866.652.2100



Case # 5 - Workstation Components



WHEN DISASSEMBLING TIGHTEN ALL BLACK KNOBS TO PREVENT LOSS DURING SHIPPING

Case # 6 - Workstation Components

