

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



Using Your Setup Instructions

The Visionary Designs Setup Instructions are created specifically for your configuration. They are laid out sequentially, including an exploded view of the entire display, and then a logical series of detailed steps to assemble the main structure and components. We encourage you to study the instructions **before** attempting to assemble your exhibit.

Each page reminds you to tighten the setscrews after disassembling your exhibit to prevent loss of the locks and setscrews (see below in RED). This is VERY IMPORTANT.

Cleaning and Packing Your Display

- 1) Use care when cleaning aluminum extrusion or acrylic inserts. Use only non-abrasive cleaners.
- 2) When cleaning laminate inserts or countertops, use mild cleansers and a soft material such as cotton.
- 3) Keep all display components away from extreme heat and long exposure to sunlight to avoid warping and fading.
- 4) Retain all packing material. It will make re-packing much easier and will reduce the likelihood of shipping damage.



The Tool

Most Visionary Designs exhibits can be assembled with the supplied Hex Key Tool. Occasionally, a flat head screwdriver may be required.




Typical Connection



Typical Connection (cont'd)

Most horizontal extrusion connections have a patented expandable lock. This lock inserts into the groove of an opposing extrusion. Tightening the lock with the Hex Key Tool expands the lock and creates a strong positive connection.




Numbered Label

Each extrusion contains a numbered label which corresponds with setup instructions. The label is located within a groove of the extrusion (when possible). With Visionary Designs the labels contain Black numbers unless otherwise specified.




Horizontal Inline Connection (remove only one setscrew)

Remove only (1) setscrew when disassembling. Replace setscrew in extrusion after assembling it. Before packing, replace setscrew in extrusion to avoid losing it.



Base Plate Connection

Attach base plate to round or square vertical extrusion using the bolt provided. Be careful not to strip the threads.



Vertical Connection (remove only two setscrews)


When vertical extrusions are packed in portable cases rather than crates or tubs, they must be broken down into smaller sections which then require assembly.

Remove only (2) setscrews when disassembling. Replace setscrews in extrusion after assembling it. Before packing, replace setscrews in extrusion to avoid losing them.

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



| Item | Qty. | Description |
|-------|------|---|
| 1 | 1 | Oval Base Plate |
| 2 | 1 | 84" Vertical Extrusion w/ Canopy Attachment |
| 3 | 1 | 84" Vertical Extrusion |
| 4 | 1 | 83.75" Vertical Extrusion w/ Canopy Attachment |
| 5A/5B | 1/1 | 28" Horizontal w/ Velcro attached to Back of member |
| 6A/6B | 1/1 | 52" Horizontal w/ Velcro attached to Back of member |

- Steps**
- 1) Attach Vertical extrusion [4] to the Oval base plate [1].
 - 2) Attach Horizontal extrusions [5A, 5B, 6A and 6B] between vertical extrusions [2, 3 and 4] as shown.
- note: Velcro on Lower Horizontals must face towards BACK.
Velcro on Upper Horizontals must face towards BACK.



Note: Attaching Graphics
Attach Backwall Graphics to Velcro
on Back side of Extrusion





Note: Attaching Graphics
Attach Backwall Graphics to Velcro
on Back side of Extrusion



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL
SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

| Item | Qty | Description |
|------|-----|--|
| 7 | 2 | 38"n Round Vertical Extrusion |
| 8 | 1 | 38"n 135° Vertical Extrusion w/ Door Stop |
| 8a | 1 | 38"n 135° Vertical Extrusion w/ Door Hinge |
| 9 | 4 | 12.5"w Horizontal Extrusion |
| 10 | 2 | Curved Horizontal Extrusion |
| | 4 | Internal Shelf Support |

- Steps
- 1) Attach Vertical extrusions [8 and 8a] to vertical extrusions [7] as shown below.
 - 2) Attach lower horizontal extrusions [9 and 10] between vertical extrusions [7/8] as shown.
 - 3) Place inserts and door where indicated.
 - 4) Attach upper horizontal extrusions [9 and 10] between vertical extrusions [7] as shown.
 - 5) Insert internal shelf and set atop velcroed supports.
 - 6) Place center atop assembled pedestal.




SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

| Item | Qty. | Description |
|------|------|---------------------------------------|
| 11 | 1 | 5.862" w Vertical Extrusion |
| 12 | 1 | 5.862" w Vertical Extrusion |
| 13 | 1 | 80.638" w Formed Horizontal Extrusion |
| 14 | 1 | 78" w Horizontal Extrusion |

Steps

- 1) Attach Sign using standoff barrels and caps.
- 2) Attach wings using A10 clamps as shown.
- 3) Attach literature racks and Monitor Mount as shown.
- 4) Connect vertical extrusions [11 and 12] to left and right side of horizontal extrusion [14] which is permanently attached to canopy.
- 5) Attach formed horizontal extrusion [13] atop vertical extrusions [11 and 12].
- 6) Attach header to assembled backwall as shown.

Attach monitor brackets to back of monitor.




Hook monitor brackets over top of wall plate, then secure with safety bolts to bottom of monitor brackets.

Modul Extrusion


Attach wall plate to vertical extrusion using supplied bolts

Wing Attachment

Slide A10 Clamp into groove of square extrusion.



When desired location is found, tighten set screw to secure.




Tighten black plastic set screw to secure Wing in place.



Black Plastic Set-screw

Connect Header Pieces together and apply Graphic to BACK of Header.


Literature Rack Attachment




Tighten lock to secure literature rack.

Standoff Barrels and Caps

Sign Attachment



Slide stand off barrels into groove of backwall extrusion




Secure Sign to stand off barrels using stand off caps

WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING

| Item | Qty. | Description |
|------|------|-------------------------------|
| 15 | 1 | 18"D Round Base Plate |
| 16 | 1 | 80"h Round Vertical Extrusion |
| 17 | 1 | 36"h Round Vertical Extrusion |

- Steps**
- 1) Attach vertical extrusions [16 and 17] to base plate [15] as shown.
 - 2) Attach tapered plex wing to front of vertical extrusion [17] using standoff caps and round sign to vertical extrusion [16].
 - 3) Place and attach counter atop vertical extrusion [17].





Sign Attachment


stand off barrel

Slide stand off barrels into groove of vertical extrusion

Secure Sign to stand off barrels using stand off caps




WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING



Level 3



Level 2



Level 1



WHEN DISASSEMBLING ALUMINUM EXTRUSION, TIGHTEN ALL SETSCREWS AND LOCKS TO PREVENT LOSS DURING SHIPPING